

Download a Composite Tool

1. Click on the link associated with the desired tool.
2. In the Download Dialog box, select the Save option.
3. Make a note of the directory where you save the downloaded file.
4. When the download is complete, install the Composite Tool.

Install a Composite Tool

1. Start IMPACT VPM and connect to the desired device.
2. Click on the Utilities tab, then click on the File Manager tab.
3. In the directory tree on the left side of the File Manager, open the directory where you saved the downloaded file.
4. Select the file in the file list and click the Copy button.
5. In the directory tree on the left side of the File Manager, open the directory named “IMPACT Root (/)” and select the directory named “Composite Tools” under it.
6. Click the Paste button to put the file into the directory.
7. Select the checkbox in the column named Load On Startup.
8. Close and Restart VPM. When you open the Tool pallet named in the Pallet Folder, the Composite Tool should be displayed.